



Tent Assembly Manual Core Relief Items

# Viva<sup>™</sup> Family Tent


ICRC/IFRC Standard


































































# $Viva^{\mathsf{TM}}$ Family Tent - ICRC/IFRC Standard





























# $Viva^{\mathsf{TM}}$ Family Tent - ICRC/IFRC Standard



























#### General Usage Notes:

- Window flaps can be opened and closed according to user requirements. To open, roll up and secure with the toggles.
- To open the front and back door flaps, roll up and secure with the toggles. To close door flaps, roll down and use the lacing system to secure each side.
- Internal ventilator window flaps and door flaps can be opened and closed according to user requirements. To open, roll and secure with the toggles.
- Roof ventilator flaps can be opened and closed by using the Velcro.
- Internal window flaps can be opened and closed by using the Velcro.